



PAKETINHALT



Stativ



Fixierstange



Tafel-Halterung



Tragetasche

# AUFBAUANLEITUNG



1 Platziere die Füße des Stativs auf dem Boden.



2 Öffne die Fixierklappen an den Stativfüßen, um diese auf die gewünschte Höhe ausziehen. Fixierklappen wieder schließen.



3 Löse nun die entsprechenden Schrauben, um die Haken auf die gewünschte Höhe für die Tafel-Halterung zu stellen.



4 Hänge die Tafel-Halterung in die Haken ein.



5 Setze die Fixierstange zusammen mit der Taktiktafel ein. Fixierklappe schließen.



6 Öffne nun die Schnalle an der Fixierstange um die Tafel zu befestigen. Schnalle wieder schließen und fertig ist das Stativ!



**INCLUDED**



tripod



fixing pole



board holder



carry bag

# ASSEMBLY INSTRUCTIONS

1




Place the feet of the tripod on the ground.

2



Open the fixing flaps on the tripod feet to extend them to the desired height. Close the fixing flaps again.

3



Loosen the appropriate screws to set the hooks to the desired height for the board holder.

4



Hang the board holder on the hooks.

5



Insert the fixing pole together with the tactics board. Close the fixing flap.

6



Now open the buckle on the fixing pole to fix the board. Close the buckle again and then the tripod is ready!